





FOXSIM

Energy response for a 2-shell Wolter-I figure for different focal lengths.



F = 1500




F = 1000




F = 500




F = 400




F = 300




F = 250




F = 200 - FOXSI rocket



F = 190




F = 180




F = 170

Histogram generated rays




Histogram caught rays on detector




F = 160

Histogram generated rays




Histogram caught rays on detector




F = 150



Histogram generated rays





Histogram caught rays on detector





F = 140





F = 130





F = 120



F = 110



F = 100



```
from foxsisim.module import Module
from foxsisim.detector import Detector
from foxsisim.source import Source
from foxsisim.plotting import plot,scatterHist
import matplotlib.pyplot as plt
import numpy as np

max_energy = 30.0
def spectrum(z):
    if (type(z) is not type([1])) and (type(z) is not type(np.array(1))):
        x = np.array([z])
    else:
        x = np.array(z)
    return np.piecewise(x, [x < 0, ((x < max_energy) & (x > 0)), (x >= max_energy)], [0, 1./max_energy, 0])

source_distance = -1e4 ##cm
source = Source(type='point', center=[0, 0, source_distance])
source.loadSpectrum(spectrum)
energies = np.arange(-10, 60, 0.1)
plt.plot(energies, source._spectrum(energies))
plt.xlabel('Energy [keV]')
plt.title('Source Spectrum')
plt.show()

module = Module(radii=[5.151,4.9],focal=200.0)
detector = Detector(width=8,
                    height=8,
                    normal = [0,0,1],
                    center = [0,0,230],
                    reso = [1024,1024])

rays = source.generateRays(module.targetFront, 500)

plt.figure()
plt.hist([ray.energy for ray in rays], normed=True, label='generated rays')
plt.xlabel('Energy [keV]')
plt.title('Histogram generated rays')
plt.legend()
plt.show()

from datetime import datetime
tstart = datetime.now()

# pass rays through module
module.passRays(rays, robust=True)
# catch rays at detector
detector.catchRays(rays)

rays_on_detector = len(detector.rays)
print('Number of rays on Detector ' + str(rays_on_detector))
print('Time total: ' + str((datetime.now() - tstart).seconds) + ' seconds')
print('Time per ray (s): ' + str(rays_on_detector / float((datetime.now() - tstart).seconds)))

drays = [ray for ray in rays if ray.des[2]==230.0]
scatterHist(drays)
plt.show()

plt.figure()
plt.hist([ray.energy for ray in detector.rays], normed=True, label='rays on detector',color='r')
plt.xlabel('Energy [keV]')
plt.title('Histogram caught rays on detector')
plt.legend()
plt.show()
```